


How to use your Acer computer at home.

The Acer computer has two mini-hard drives, one is used at school, the other is used at home. To use your computer at home you must select the correct option when you first turn on the computer.


When you turn on the computer, you will see the following screen.



Make sure you pick the one which says "Home"

Use the arrow keys to select the "Home" option.

Press Enter and your computer will start up into the Home configuration, and the login screen will appear, as shown below.



You need to select "User" option from the two icons displayed.

Just click "User" – there is no password set.

To add your computer to your home network, please refer to your ISP configuration details.